



CORIOmaster2 Mobile App User Manual (Android & iOS)

Overview

CORIOmaster2 Mobile is a remote control application that provides seamless management of the CORIOmaster2 video wall processor. Designed for AV professionals who require on-the-go flexibility, the app allows users to:

Switch video window sources.

Trigger layout presets instantly.

Adjust and mute audio levels per canvas.

Control multiple CORIOmaster devices from a single interface.

Whether you are overseeing a live event or fine-tuning a complex installation, CORIOmaster2 Mobile offers intuitive, powerful control right from your mobile device.

Installation Guide

For iOS Devices:

1. Open the App Store.
2. Search for CORIOmaster2 Mobile.
3. Tap "Get" to install.
4. Open the app and grant any requested permissions.

For Android Devices:

1. Open the Google Play Store.
2. Search for CORIOmaster2 Mobile.
3. Tap "Install".
4. Open the app and allow necessary permissions.

Account Setup

1. Launch the App.
2. Add your device using device settings and credentials.
3. Connect to CORIOmaster:
 - Ensure your mobile device and CORIOmaster2 are on the same local network.



CORIO**master2**

Devices

My CM2
172.16.21.35




Feature Guide

Changing the Window Source

This feature allows you to choose which video source is displayed in any specific window.

Steps:

1. Connect to CORIOmaster and go to Windows Tab.
2. Tap on the window you want to edit.
3. A list of available input sources appears (e.g., HDMI, SDI).
4. Tap the desired source.
5. The new source will display live in the selected window.



Recalling Presets

Presets are pre-configured setups for window layouts and sources.

Steps:

1. Open the Presets Tab.
2. Select a preset (e.g., "Full Screen," "Quad View").
3. Layout and source changes are applied immediately.




Adjusting Canvas Audio

This feature lets you control audio levels for each canvas.

Steps:

1. Go to the Canvas Tab.
2. Select the canvas.
3. Adjust volume with the slider.
4. Use Mute/Unmute to toggle sound output.



Tips & Troubleshooting

- Ensure Wi-Fi/network connectivity between device and CORIOmaster.
- Update the app regularly for new features and bug fixes.
- Restart both mobile device and CORIOmaster unit if connection fails.
- Use clear preset names for quick recall during live operation.

Support Information

- Email: support@tvone.com
- Web: <https://help.tvone.com/r/cm2m/1/1>